



Philips Consumer Lifestyle

# Service Manual

## PRODUCT INFORMATION

### Safety info

- This product meets the requirements regarding interference suppression on radio and TV.
- After the product has been repaired, it should function properly and has to meet the safety requirements as officially laid down at this moment.

- SAP coding : HD9225/50  
HD9225/51  
HD9225/52  
HD9225/53  
HD9220/50

### OPTIONAL (accessories)

- Baking dish 4222 459 52761

## TECHNICAL INFORMATION

- Voltage : 220 - 240 V
- Frequency : 50 - 60 Hz
- Power consumption : 1425 W
- Product dimensions (W x H x D) : 287 x 315 x 384 mm
- Cord length : 1 meter
- Materials : Outer skin : Plastic (PP)  
Pan : Aluminized steel  
Basket : Aluminized steel  
Basket mesh : Stainless steel  
Coating : PTFE coating
- Capacity : 2.2 liter  
(till max indicator)
- Weight : 7.0 kg
- Coloursetting : Star white /  
Cashmere grey
- Temperature : 80 till 200 °C
- Fuse cut-off temp. Motor : 145 °C  
TCO : 190 °C

### IMPORTANT:

**When you replace the pan (basketholder) or basket, first check production week on the bottom of the appliance to find out which part(s) you need to order:**

HD9225/5x	Pan		Basket	
HD9220/5x				
1111	4222 459 54161	and	4222 459 54151	Due to compatibility issues, make sure you order both components
1111 > 1136	4222 459 54161	or	4222 459 52711	Components are compatible no need to be ordered both at once
> 1136	4222 459 54161	or	4222 459 54151	Components are compatible no need to be ordered both at once

Part/ System	Test	Possible deviation	Analyses	Replace (depending of the analyses outcome)
Timer	Check if the green light is lit, and if you can hear the timer ticking	The green light is not lit but the timer is ticking	Check the timer-switch and the fuse with a multimeter	Timer/Fuse
		The green light is lit but the timer is not ticking	Timer is defective	Timer
Thermostat	Set the temperature at 80 °C and check if the heating element is getting warm (Check input power approx. 1425 W) The green light should be lit and the orange light should switch off after it reaches 80 °C	Both green and orange light are lit but there is no heating	Check the heating element with a multimeter	Heating element
		If the green light is lit and the orange light is off	Check the thermostat with a multimeter	Thermostat
		If both the green and orange light are off	Check the timer and fuse with a multimeter	Timer/Fuse
		The orange light does not switch off after reaching approx. 80 °C	Thermostat is defective	Thermostat
Motor fan assy	Set the timer and listen if the motor is running	Motor is not running	The fan is scraping the housing turning it by hand (Switch off the power when you do this test!)	Motor fan assy
			The fan is not scraping the housing turning it by hand (Switch off the power when you do this test!): Check the motor fan assy, timer and fuse with a multi meter	Motor fan assy / Timer/Fuse
Heating element	Check if the heating element is getting warm (Check input power approx. 1425 W)	If the Orange light is on and the heating element does not heat	Check the heating element with a multimeter	Heating element
		If the heating element does not heat and the orange light is off	Check the timer, fuse and thermostat with a multimeter	Timer/Fuse/ Thermostat
Thermal fuse	Set the timer and check if the green light is lit	Green light is not lit	Check the timer and fuse with a multimeter	Timer/Fuse


**General remark;**

When you need to disconnect a wire from the crimp housing, please cut the wire half way (See 3< in the picture below) and always connect the wires with a new 2 wire crimp housing 4222 459 51851. To crimp the housing use the Lobster AK25 No2 or Muromoto Tekko MR30A Nr 2 with Air pressure = 6 kg/cm<sup>2</sup>.

**Crimp instruction CE2**


- 1) Strip wires: 16mm (0.63 in) Max. 13mm (0.51) Min.
- 2) Twist the wires together along the entire length of the strip and insert them into crimp housing .
- 3) Center the crimp tool on the sleeve.
- 4) Crimp the housing with 6 kg/cm<sup>2</sup>.

**Route the wire route, using 5 tie-wraps according the picture below;**




### A. Top cover removal

1. Open the cover from the top cover by using a flathead screw driver to open the 6 click connections.




2. Use a crosshead screw driver to unscrew the 4 screws **A**.


**Note:** When you close the top cover, use a screw torque off 50 till 80 Nm (5 to 8 kgf.cm)



3. Use a flathead screw driver to open the “timer top cover” and pull the knob from the appliance.



4. Unscrew the screw **B** under the timer top cover.




**Note:** Replace the timer cover and / or the cover in case of damage and / or scratches.

**Tip:** Open the “timer cover” from the bottom side, to avoid scratches on visible places.


### B. Cover housing removal

1. Follow previous step **A**
2. Open the motor fan assy from the base by unscrewing the 6 screws **C**. Be aware of the 2 screws under the filter.




### D. Double heat shield removal

1. Follow previous step **A, B** and **C**
2. Remove the double heat shield out of the motor fan assy by unscrewing the 3 screws **E**.




### C. Heating element + Fan Removeval

1. Follow previous step **A** and **B**
2. Undo the heating element from the double heat shield by unscrewing the 3 screws **D**.



### E. Timer removal

1. Follow step **A**
2. Unscrew the 2 screws **F** behind the timer knob.




3. Remove the wires of the timer.

3. Cut the 2 heating element wires halfway and remove the heating element.
4. Undo the nut from the left screw thread and remove the fan.


## F. Thermostat removal

1. Follow previous step **A**
2. Remove the 3 screws **G** from the thermostat assy.




3. Follow previous step **B, C, D**  
By step **C** do not cut the wires.
4. Remove the thermostat sensor by undoing the metal band.

**Note:** be careful with the wire / heating element connecting, this connection is fragile.




**Note:** Please make sure while re-assembling the new thermostat that the routing will be done as shown in below picture.




## G. Motor assy removal

1. Follow previous step **A, B, C, D**  
By step **C** do not cut the wires.
2. Remove the thermostat sensor (See instruction **F 4**)
3. Remove the fuse and the earth connection from the double heat shield.



4. Cut the motor wires half way and remove the motor fan assy.





Pos	Service code	Description	
1	4222 459 5277I	Cover	Cashmere grey
2	4222 459 5269I	Timer knob	Black
3	4222 459 5270I	Timer cover	Oyster Metellic
4	4222 459 5190I	Food separator	
5	4222 459 5271I	Basket	<wk1136 Cashmere grey
	4222 459 5415I		>wk1136
6	4222 459 5272I	Pan (Basket holder)	Star white
7	4222 459 5191I	Rubber foot	<wk1116
	4222 459 5467I	Rubber foot	>wk1116
8	4222 459 5273I	Top cover	Star white
9	4222 459 5325I	Stainless steel timer	
10	4222 459 4918I	Fuse incl. wires	
11	4222 459 4914I	Fan	
12	4222 459 4913I	Heating element incl. wires	220-240 V, 50 Hz
	4222 459 5339I	Heating element incl. wires	220-240 V, 60 Hz
13	4222 459 5274I	Base incl. wires	Star white
14	4222 459 5275I	Thermostat assy	
15	4222 459 4920I	Motor, fan assy	220-240 V, 50 Hz
	4222 459 5340I	Motor, fan assy	60 Hz
16*	4222 459 5276I	Baking dish	
	4222 459 5185I	10 pieces of 2 wire crimp housing (CE-2)	

\* **Optional for HD9220/50**

### Electrical circuit

When the appliance does not work, check the electrical circuit.

Open de lid panel always on the underside. Always replaces this panel in case of damaged, scratches body or broken click connection.

